


## ESC、ESU、ESF气缸安装附件

### TC型附件



缸径/型号 Inner Dia./Code	EB	EC	ED	EE	EG	EP	ET	S
32	90	53	33	56	17	12	26	37.5
40	113	63	37	63	25	25	26	45.5
50	126	76	47	76	25	25	26	55.5
63	138	88	56	88	25	25	26	68.5
80	164	114	70	114	25	25	30	87.5
100	182	132	84	132	25	25	35	107.5
125	210	158	110	154	28	25	37	134