


## ESC、ESU、ESF气缸安装附件

### U型附件



缸径/型号 Inner Dia./Code	PA	PB	PC	PD	PE	PF	PG	PH	PI	PJ	PK	PL	PM
32	10	14	10.5	12.9	26	43	56	M10X1.25	20	19	15	6.5	17
40	12	16	12	15.4	30	50	65	M12X1.25	22	22	17.5	6.5	19
50	16	21	15	19.3	38	64	83	M16X1.5	28	27	22	8	22
63	16	21	15	19.3	38	64	83	M16X1.5	28	27	22	8	22
80	20	25	18	24.3	46	77	100	M20X1.5	33	34	27.5	10	32
100	20	25	18	24.3	46	77	100	M20X1.5	33	34	27.5	10	32